PRINTING INFO

DIE LINE

FOLD LINE

FRONT

ifrogz

Pop

= Bluetooth SPEAKER =

PAGE 1

Warranty Registration

Your **CODA POP** speaker comes with a **one-year manufacturer's warranty.** In order to activate the warranty, you **must register your CODA POP** as well as keep your purchase receipt. If you purchased your CODA POP from ZAGG.com, ZAGG® has already registered it and has a copy of your proof of purchase. iFrogz® is a ZAGG® Inc brand.

NEED MORE HELP? PLEASE SEE OUR FAQ SECTION AT: www.ZAGG.com/faq

PAGE 2

Powering On and Off

To turn your CODA POP on, simply **slide the selector switch on the bottom to Bluetooth® or AUX.**

If you choose Bluetooth, the LED light will show red, then, as the CODA POP powers up, you will hear the pop tab sound indicating it is ready to pair. The LED light will also begin alternating between red and blue.

To turn your CODA POP off from Bluetooth mode, simply slide the **selector switch to OFF.** The CODA POP will power down with a refreshing fizz tone.

PAGE 3

If you choose to turn on your CODA POP **using the AUX option, no tone will sound.** Simply **plug your 3.5mm cable into the speaker** and your music device, **slide the selector switch to AUX,** and then begin enjoying your music.

To turn your CODA POP off from AUX mode, simply slide the **selector switch to OFF**. No tone will sound.

Pairing Your CODA POP

Pairing your CODA POP with your music device is quick and easy. It should only need to be **paired once** using the following directions. If the **connection** between the **CODA POP and your device is ever lost**, simply **repeat these steps.**

PAGE 4

1. Make sure your device's **Bluetooth® connection is enabled.** You can do this on many devices by accessing the **SETTINGS** menu then choosing **GENERAL > BLUETOOTH® > ON**.

2. Turn your CODA POP on by sliding the selector switch to the Bluetooth® option. Wait for the pop tab sound that indicates it is ready to pair.

3. Your music device will show "CODA POP" as an **available device.** Select this option to begin pairing.

4. When the CODA POP is paired with your device, the **LED light will flash blue** periodically.

5. Enjoy the refreshing sounds of your music.

PAGE 5

Listening Via AUX

To enjoy the powerful sounds of your CODA POP using the **AUX mode,** simply follow these steps:

1. Plug a 3.5mm cable into the AUX port.

2. Connect your music device by using the other end of the 3.5mm cable (or AUX cable).

3. Slide the selector **switch to AUX.**

4. Make sure both ends of the 3.5mm cable are seated properly and begin playing your music from your device.

5. Enjoy.

PAGE 6

Switching Between Bluetooth® and AUX Modes

If you are enjoying your CODA POP in **Bluetooth® mode** and want to **switch to AUX,** you must **first power the CODA POP down completely** and wait for the **power down tone** to sound. Only after the power down tone has sounded can you then **switch to AUX mode** and begin enjoying your music via a **3.5mm cable.**

If you wish to switch from **AUX to Bluetooth®,** you can simply **slide the selector switch to Bluetooth®** and **pair the CODA POP to your music device.** You do not need to wait for it to power down.

PAGE 7

Charging Your Coda Pop

Your CODA POP comes with a **battery that packs a punch** and can keep your music flowing until the party's over. **When you do need to charge it, simply follow these steps:**

1. Plug the included power cord into the CODA POP's DC jack.

2. Plug the USB end of the included charging cable into the charging device you prefer (ZAGG Spare, your computer, a wall outlet converter, etc.).

3. While your CODA POP is charging, the **LED light will be red.**

PAGE 8

4. When **charging is complete the LED light will turn blue.** It typically takes 2-3 hours for the CODA POP to charge fully.

5. When **fully charged,** your CODA POP speaker provides **2-3 hours of continuous music.**

Conference Calls

Your CODA POP also allows you to **take calls hands-free. Its built-in microphone** transmits your voice cleanly while the Coda Pop speaker projects their voice crisply and clearly. **To take a call on your CODA POP, follow these steps:**

PAGE 9

1. Restart your music device.

2. Turn your CODA POP off and back on. You should see the **LED light illuminate**, if not, charge your CODA POP. Note: If you are **powering off** from Bluetooth® mode, **make sure you hear the power down** tone. If you don't hear it, charge your CODA POP.

3. After charging, turn your CODA POP on. If the LED light still does not illuminate, and your speaker doesn't operate correctly, please contact ZAGG's customer support.

4. Forget and re-pair your CODA POP. On your device select: **= SETTINGS > GENERAL BLUETOOTH > ON.** If you see **"CODA POP"** listed as an available device, **select it and choose to have**

PAGE 10

your device forget the speaker.

5. Re-pair your CODA POP with your **device by sliding the selector switch to Bluetooth®.**

6. Your music device should display "CODA POP" as an available device. Select it.

7. If your music device gives you an **error message, repeat the pairing process*.**

If you continually receive the same error message during pairing, or the above steps don't work, please contact ZAGG's customer support for assistance.

For more help please see our FAQ at: www.ZAGG.com/faq

BACK

To reach a trained customer service representative, please use one of the following:

- **ZAGG.com/support/contact.php**
- **questions@zagg.com**
- **1-800-700-ZAGG [9244]**
- **00-1-801-839-3906** for international customers

©2005 - 2013 ZAGG Inc All Rights Reserved.
NASDAQ: ZAGG | MADE IN CHINA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. This device must accept any interference received, including interference that may cause undesired operation.